

# Installing Cowl Vents

Nicro Cowl Vents install using the same Snap-In deck plates as the Day&Night 2000. Please refer to the instructions beginning on page 25 for deck camber, marking and cutting the hole and installing the deck plate. The 3" snap-in cowl vent requires a 3-3/4" installation hole, the 4" snap-in cowl vent requires a 4-3/4" installation hole. The 3" threaded cowl requires a 3-3/8" installation hole; the 4" threaded cowl requires a 4-3/8" installation hole.

